


# Frothee **Rotary Rug Shampoo**

Champú de Alfombra Para Equipo Rotativo

- Concentrated High Foaming
- Cleans
  Quick-Acting



# **Technical Data Sheet**

### **PRODUCT DESCRIPTION:**

A super concentrated, high foaming formulation containing detergents, surfactants, polar solvents and optical brighteners to quickly remove stubborn dirt and soil from carpeting and upholstery.

#### **USES:**

For use with rotary machines. Safe to use on most types of fabrics.

# **ADVANTAGES:**

High foaming action lifts soil to the surface. Low wet out will not saturate carpeting or backing which reduces mildew and foul odors. Highly concentrated and quick drying. Visually brightens carpet colors.

# **SPECIFICATIONS:**

**Active Ingredients: 24%** 

8:Hq **Color: Clear** 

Solubility in Water: Complete

**Odor: Lemon** Flash Point: None **Viscosity: Water Thin** Weight per Gallon: 8.8 Lbs.

# PRODUCT/CONTAINER **DISPOSAL:**

Dispose of used/unwanted product according to state and local regulations. Offer container for recycling.

# **SIZES AVAILABLE:**

1 Gallon Bottle, 5 Gallon Pail, 30 & 55 Gallon Drums.





### **PRODUCT USE**

#### **DILUTION RATE**

**Rotary Shampoo** 

3-4 oz. per gallon of water

#### **DIRECTIONS FOR PRODUCT USE:**

- 1. Pre-test carpet for colorfastness in an inconspicuous area at recommended use dilution. Use clean cloth or sponge for application and if test area indicates bleeding, color removal, carpet shrinkage or deterioration of adhesive, do not use.
- 2. Remove furniture and dry vacuum thoroughly.
- 3. Pre-treat spots and traffic lanes.
- 4. Using rotary machine, shampoo across carpet in overlapping passes.
- 5. Avoid over-wetting carpet and if available use vacuum to pick up excess liquid.
- 6. Brush carpet in one direction with deck or pile brush.
- 7. Do not walk on carpet until completely dry. Vacuum thoroughly when dry.
- 8. For upholstery use, follow colorfast pre-testing prior to use. Apply with a sponge, vacuum any residual foam and allow to dry. A final brushing & vacuuming is recommended.



It is recommended that protective gloves and safety glasses be worn when using this and all cleaning products.

Refer to SDS for further safety information.









